

Air Conditioner (A/C)

In the back house



Oeko Air conditioner (*)

Location air conditioner:

Under the ceiling

(*) The air conditioning is centrally controlled and adapts to the temperatures outside and reduces them by a few degrees.

Location thermostat:

At the entrance or in the room

Turn on

- 1) Press to light up the two symbols.
- 2) Both symbols must light up.
- Turn to set the temperature to minus or plus.

Turn off

4) Press the button (1) until the light goes out.

In the corner house



Location air conditioner:

Above the entrance door

Location thermostat:

At the entrance or in the room

Turn on

- 1) When turning on the air conditioner, slide the switch to the "snowflake" position.
- ,,
- 2) Set the temperature.
- 3) Set the desire speed.

Turn off

4) Set the switch to the "0" symbol.

In the front house









Location air conditioner:

Above the entrance door

Location operator panel/touch screen:

At the entrance or in the room

Turn on

- 1) Set the desired language.
- 2) Press on the temperature.
- 3) Turn the round rotary button.

- Set the desired temperature.
- 5) Press the rotary button to confirm the temperature.
- 6) Press the mode button.

-) Press the button and select the speed.
- Confirm the process by pressing the rotary button.

Turn off

- 9) Turn the button (9) until the symbol (7) shows "zero"
- 10) Cornfirm the button (8) b
- 11) y pressing it.

.....



Klimaanzeiger "special"




Location air conditioner:

Above the entrance door

Location thermostat:

At the entrance or in the room Turn on

- 1. Touch the touch screen when switching on the a/c, the clock opens and the window. with the selections follows.
- 2. Touch the field of the a/c system and then the filed for the temperature setting opens.



Turn off

5. Press "—" button and set to zero, press the confirmation button.



GAIA Hotel I Come as a guest, leave as a friend